

Assembly and Installation Instructions for Model

50012/130DW

CAUTION - RISK OF FIRE

Installation of this fixture should be done by a licensed electrician or by a person familiar with local electrical codes and the construction and operation of this fixture.

Warning please make sure the electrical breaker is shut off before commencing with this installation
Read and familiarize yourself with these instructions before commencing

This fixture is certified for wall or ceiling mounting and is suitable for Wet locations and dimmable with most dimmers.

Package Contents

Part	Description	Qty
A	Mounting plate	1
B	Junction-Box mounting screws	2
C	Electrical wire connectors	3
D	Base rubber gasket	1
E	Fixture assembly	1
F	Fixture mounting nuts	2
G	Miter glass assembly	1
H	Top shelf	1
I	Miter glass screw and washer	1
J	Bottom shelf	1
K	Fixture mounting screws	4

Installing the fixture *please ensure the electrical breaker is switched off before commencing*

- 1 Attach the supplied Mounting plate (A) with the two supplied mounting screws (B) to the Junction-Box.
- 2 Attach the supplied Base rubber gasket (D) to the back rim of the Fixture Assembly (E)
- 3 Connect the supply wires to the fixture wires using the supplied Electrical wire connectors (C). White supply wire to the White fixture wire, Black supply wire to Black fixture wire and the ground Bare Copper or Green wire to the Green fixture wire. Once the electrical wire connectors are securely fastened it is recommended to tape these connectors with electrical tape.
- 4 Attach the Fixture Assembly (E) to the Fixture mounting bracket (A) and secure with supplied Fixture nuts (F).
- 5 Attach the Top shelf (H) to the Miter glass assembly (G) and secure in place with Miter glass screw and washer (I).
- 6 Attach the Miter glass and Top shelf assembly (G/H) to the Fixture assembly (E) and secure with Fixture mounting screws (K). Slide the Bottom shelf (J) to the base of the Miter glass assembly (G) and secure with Fixture mounting screws (K).
- 7 Switch on the electrical breaker switch and your new fixture is ready for many years of trouble free use

